

PREFACE

Thank you for choosing a motorcycle of the company. May you enjoy riding all the time.

The manual contains the necessary instructions and guidance with respect to the operation and maintenance of the motorcycle, and **BE SURE TO READ IT CAREFULLY BEFORE YOU RIDE THE MOTORCYCLE.** Proper operation and maintenance can guarantee a safe riding to minimize troubles of the motorcycle and keep it in a sound condition, which can extend the engine service life. Your dealer will provide you with technical inquiry and after-sales service.

The technical data in the manual are the latest, and we reserve absolute right to amend them. The manual is subject to change without notice. Please check carefully the product nameplate, VIN record and engine code in the motorcycle, which you have bought, and they are helpful for you to get the motorcycle a license plate and for future inquiry.

Important Notice

Operator and passenger

This motorcycle is designed to carry the operator and one passenger. Never exceed the maximum loading capacity as specified in the manual.

Maximum load

150 kg.

On-road use

This motorcycle is designed to be used only on the road.

READ THIS OWNER'S MANUAL CAREFULLY

Pay special attention to statements preceded by the following words:

WARNING

Indicates a strong possibility of severe personal injury or death if instructions are not followed.

CAUTION

Indicates a possibility of personal injury or equipment damage if instructions are not followed.

Note: Gives helpful information.

This manual should be considered as a permanent part of the motorcycle and should remain with the motorcycle when resold.

CONTENTS

MOTORCYCLE SAFE RIDING	2	Main Switch	4
Safe Riding Rules	2	Instruments and Indicator	4
Protective Cloths	2	Handlebar Controls	4
Refitting	2	Clutch Lever	5
Loading and Accessories	2	Gearshift Pedal	5
PARTS LOCATION AND VIN RECORD	3	Front Brake Lever	5
Parts Location	3	Rear Brake Pedal	5
VIN Record	4	Fuel Filler Cap	5
CONTROL FUNCTION	4	Fuel Cock	5
		Choke lever	5